




FASTENation[®]
FASTENING YOUR WORLD TOGETHER

APPLICATION GUIDELINES FOR PRESSURE SENSITIVE ADHESIVES

Surface Preparation

When applying your pressure sensitive (adhesive) fastener, it is extremely important to thoroughly clean and dry your application surface. Prior to use, test your cleaning agent on a sample and attempt to apply it to be sure it does not adversely affect the bond. For best results, adhesive should be applied at a room temperature of 68°F or higher. If adhesive must be applied at a temperature below 68°F, warm the tape and surface prior to applying to ensure optimal bonding.


Note: Pointed corners may be detrimental to a good bond. Nipping or rounding each corner will help eliminate this vulnerable area.



1. Using a cloth and rubbing alcohol, thoroughly clean & dry surface prior to application. Avoid any cleaner that may leave a film or oily residue on the surface.



2. Peel release liner from back of tape being careful not to touch the adhesive with your fingers.



3. Apply tape to surface and allow time for it to fully bond (see our adhesive guide for recommended bonding time based on your adhesive type).